



# **PV Module Line**

## **Operation Manual**

**[M601/602. MEGALAM-2246]**

**For Tindo Solar**

**September, 2011**

**WOOIL HIGHTECH**

# **CONTENTS**


- 1. Introduction**
- 2. Principle of Operation**
- 3. Specifications**
- 4. Installation**
- 5. System Tour**
- 6. Console Descriptions**
- 7. Control Panel Instructions**
- 8. Operating Instructions**
- 9. Alarm**
- 10. Maintenance**
- 11. Appendix : Electric Wired DWG**

## 1. INTRODUCTION

The installation, Operation and Maintenance manual is intended to provide the reader with a working knowledge of solar module laminator as,





'LAMINATOR MEGALAM+LOADING/UNLOADING CONVEYOR'



- System tour, process, and major component descriptions introduce the user to the laminator process and operation.
- The maintenance section provides introductions for maintaining and repairing the machine.
- Major system description supplies the reader with helpful information concerning assembly construction and the function of components in the process of laminator.
- This manual features a troubleshooting section to furnish the user with information to determine the root cause when problems arise.
- An illustrated parts listing is provided for repair and replacement.
- Carefully read the UNPACKING AND INSTALLATION section before performing these tasks similarly, all operators should read all sections of the manual before attempting to operate the machine.







- MEGALAM\_2246 with Loading and Unloading Conveyor -

### 1.1 Hazard labels

	<p>Statements that indicate an immediate hazardous situation that, if not avoided, will result in death or serious injury.</p>
	<p>Statements that indicate potentially hazardous situation that, if not avoided, could result in serious injury</p>
	<p>Statements that indicate potentially hazardous situation that, if not avoided, may result in moderate injury,</p>
	<p>Statements used for stating instruction or for the protection of personnel or property.</p>










## 1.2 Safety Precautions

The DANGER precaution shown in below table is intended for the protection of personnel servicing or operating the machine.

### Danger Notices

	
●	Disconnect all AC power before replacing components or servicing inside the unit. High voltage can be present in the machine that can cause personnel injury or death when the power is on.
●	The platen is extremely and after lamination. Allow sufficient cooling time or wear protective clothing to remove modules or service platen.
●	Never defeat any of the interlock switches.
●	Never operate without protective shields or covers in place over electrical components

## 2. PRINCIPLE OF OPERATION

The purpose of the LAMINATOR MEGALAM is to laminate and/or encapsulate materials to form void-free composite structures. The laminator bonds multiple layers of materials together with thermoplastic or thermosetting films. The processing chamber has temperature, vacuum, and pneumatic pressure capabilities, which are independently controlled to provide optimum processing conditions for particular materials and configurations.

The laminating cycle is an empirically determined sequence of events. The usual objective is to determine the shortest sequence which produces a good lamination without adverse side effects to any of the laminate components. The most critical part of the laminating cycle is the part prior to melting of the plastic sheet encapsulated. The amount of time with the assembly under vacuum, the time with pressure applied, the temperature with pressure applied, and the duration and quantity of pressure affect the quality of the lamination.

The laminator is programmed to perform the complete lamination and cure sequence, typically in 20 to 30 minutes for standard curing ethylene vinyl acetate (EVA) based encapsulating. An alternative laminating cycle can be done at higher throughput with standard EVA. This cycle occurs at a constant temperature below the cure temperature, and automatically laminates modules in seven or eight minutes. Modules laminated in this alternative cycle are placed in a conventional oven at cure temperature for the required time.

Regarding the fast curing EVA, a complete lamination and cure cycle lasts approximately eight to twelve minutes. No curing oven is required.

When selecting a cure cycle for either standard for either standard or fast curing EVA, it is important to measure post-laminate EVA gel content and pulls strength of EVA to the other module materials such as glass and back cover file. Adequate gel content and pull strength are required to insure that structures do not delaminate in the field.



### 3. SPECIFICATIONS

#### 3-1 Laminator Specifications

Item	Specifications
Effective Lamination Area	2200mm X 4600mm
Solar module	35mm
Vacuum System (option)	Vacuum pump: Leybold SV300 Rotary vane or SP630(Dry pump) Mechanical booster: Leybold WAU 501 or None Pressing speed: 5666 liters/min Pumping speed: the bottom of chamber, less than 133Pa/min.
Pressing Control	Pressing force: Adjustable between 0 and 1atm Pressing speed: Selectable 3speed by solenoid valves.
Platen Control	Temperature Uniformity: $\pm 2$ % (Upper Chamber closed, No load) Operating Temperature : Up to 180°C (Max. 185) Heating : Less than 30 minutes (from 30° to 120°C) Platen Control: 5 Independently PID controlled zones with the controlling thermocouple located approximately in the center of each zone. Spare thermocouple is built in each controlled zone. Over temperature safety system: Each of 5 platens is protected by an over temperature alarm in independent controller.
Module lift-up pins	Pin diameter: 5.5mm Pin lift-up height:5mm( hand adjustable) Pin lift-up and lift-down time required (Program can be set)
Chamber lifting System	Driven by 4 Hydraulic cylinders with hydraulic pump unit Movement stroke : 430mm/max (full open) lifting speed : Less than 30s (from closed Chamber to full open)
Diaphragm clamping system	The diaphragm is supported and sealed to the inside of the upper chamber by cramping frame and clamp lever with no bolts.
Cover for platens and Diaphragm	Top surface of the platen and under surface of diaphragm sheet covered by Teflon release sheet.
Operation system	PLC control: Mitsubishi Touch screen : 10.4" color display Operating Screens;

	<p>Auto Screen: To monitor “set point” and “current value” of pressure, temperature and process time of the running recipe.</p> <p>Pressure and temperature monitor screen : To monitor pressure and temperature.</p> <p>When the lower chamber is to less than 999Pa (≈-753 mmHG), it can be monitored on Pressure of ‘Lower camber [Pa]’ on this screen.</p> <p>Manual screen: To control the laminator components manually.</p> <p>Parameter screen: To set process parameters for each recipe.</p>
Safety system	<p>Light curtains.</p> <p>Front, back, right and left sides</p> <p>Effective height is Appox 260mm above the top surface of the platen.</p> <p>Heater wire detection sensors are quipped</p>
Painting	Snow white N 9.0(S)
Weight	<p>NET 12,500kg(Except Loading &amp; unloading conveyor)</p> <p>Required floor weight withstand capacity: 500kgf/m<sup>2</sup></p>
Equipment Dimensions	See attached drawing

### 3-2 Loading/ Unloading Specifications

Item	Specifications
Pass line	970mm(F,L)
Laminator lower belt conveyor	<p>Transfer method : Belt transfer system</p> <p>Feed speed: Max. 15m/min</p> <p>Drive unit: Inverter controlled electric motor</p> <p>Max. load : 110kg</p>
EVA removing brush unit	<p>Drive unit: Inverter controlled electric motor</p> <p>EVA dust tray: Can be pulled out toward operator side.</p>
Loading Conveyor	<p>Feed speed: Max. 15m/min</p> <p>Drive unit: Inverter controlled electric motor</p> <p>Max. load : 110 kg</p> <p>Work detector: Photo-electric sensor the head of solar module.</p> <p>Control box: Link with ‘1 pitch’ &amp; ‘Module set finish’ button</p> <p>Module feeding : Pitch transfer System(Timer setting : programmable )</p> <p>Operation:</p>


	<ol style="list-style-type: none"> <li>1. Place the solar module on loading conveyor by manual.</li> <li>2. Feed the module by pressing 'Loading 1 pitch' button. Pressing 'Loading 1 pitch' button activates pitch-transfer movement. Feeding timer is programmable</li> <li>3. Cover the modules by release sheet, and press 'Module set finish' button. The modules will be transferred into the laminator automatically when preparations for laminator are set.</li> </ol>
Unloading Conveyor	<p>Transfer Method : Belt conveyor system          Feed speed: Max. 15m/min          Drive unit: Inverter controlled electric motor          Mac. Load : 110Kg          Work detector : Photo-electric sensor detects the head of solar module          Operation :</p> <ol style="list-style-type: none"> <li>1. The solar module will be transferred out of the laminator automatically and stop at the end of the unloading conveyor.</li> <li>2. Remove release sheet and transport the modules to next unit by hands.</li> </ol>
System cycle time	<p>Transfer time : within 60s          Vent lower chamber &gt; Open upper chamber &gt; Transfer module &gt; Close upper chamber</p>



**Loading Conveyor**



**Unloading Conveyor**



### 3-3 General specifications

Item	Specifications
Operation temperature	0 ~ 25°C
Installation temperature	0 ~ 25°C
Operation moisture	5 ~40%RH, No condensation
Installation moisture	5 ~40%RH, No condensation
Operation environment	No corrosiveness
Operation height	Less than 3000m
Overtoltage type	Category III (According to IEC60664-1)
Pollution	Degree 3(According to IEC60664-1)
Noise	Less than 68 db

### 3-4 Facilities

Item	Specifications
Power supply	3phase 415VAC 50Hz 121kw
Compressed air	More than 0.5 Mpa , 50 liters/min Size and Type of Connection: Φ12 one touch fitting female
Vacuum exhaust	Exhaust connection on vacuum pump : 3 inch
Test equipment	Test pieces required for inspection on installation and test-operation

## 4. INSTALLATION

### 4.1 Lifting

A forklift (with a capacity of 15 ton or more) can be used to lift the Laminator.

See attached drawing. Separate table & roller from Laminator. (When already separated at manufacturer plant)

- (1) Attach 3m long forks to the forklift. The forks need to be 3m or longer to reach the other side of machine frame.
- (2) Insert forks at the marked position on the illustration. The forks need to be perpendicular to the machine frame at the listing points. Make sure that the forks reach the other side of frame.
- (3) Place a cloth or padding between the jack-up point and the roller so that the machine should not be slip on the forks.
- (4) Gradually raise the forks, making sure that a cloth or padding is still jack-up points and the machine will not slip sideways. –
- (5) Lift the machine up from the ground by about 500 mm. Do not lift up too high.

Item	Weight
Laminator	12,500 Kg
Loading conveyer	500 Kg
Unloading conveyer	500 Kg
Vacuum pump unit(option)	200 Kg
Electric Cabinet	300 Kg
Operation Panel	60 Kg

### 4.2 Moving



***Only a specialist vendor can move the machine sideways, which should be performed on a flat, level ground. Follow the work procedure given below. Failure to observe these precautions could result in a serious personal injury or machine failure.***


<Machine Moving Procedure >

- (1) Carefully and gently lower the lifted machine down onto the four rollers placed on a flat ground. Make sure that each of the jack-up points at the four corners (see the illustration) of the machine mate with each of the four rollers.
- (2) As a precaution, place a cloth or padding between the jack-up point and the roller.
- (3) Making sure that the machine will not slip sideways, gradually lower the machine.
- (4) When the ropes are loose enough, stop the crane and unhook the ropes from the machine.
- (5) Hook a rope through a hole of the reinforcing plate at the machine leveling bolts and move the

machine to the installation position using a forklift or which secured to a solid place.

- (6) When the machine has been moved to the installation position, remove the rollers one by one using a fixed-type crane (7 ton-or-more) or a hydraulic jack (2 ton-or-more) and install the machine to the foundation plate.

### 4.3 Installation requirements




Item	Specifications
Power supply	<p>More than 415VAC (<math>\pm 5\%</math> 10%) 50Hz 169A</p> <p>Primary electrical wiring directly to the Breaker in the electric cabinet (Breaker)</p> <p>Cable size: 100mm<sup>2</sup> (96.3~117.2 mm<sup>2</sup>)</p> <p>Tightening torque: 45Nm</p> <p>Terminal size: M12</p>
Compressed air	<p>More than 0.5 MPa, 50 liters/min</p> <p>Inlet Connection : <math>\Phi 12</math> female (fitting on the air panel)</p>
Vacuum exhaust	<p>Exhaust outlet on vacuum pump: G2" 1/2 female (optional)</p>

## 4.4 Utilities

### AC Power connection

Verify that main disconnect switch is in the off position. Connect 3-phase, AC 415VAC, 121kw power cable directly to main disconnect switch inside the electric cabinet. The three hot wires are connected to the top of the disconnect switch (L1, L2, L3), and the ground wire connects to the ground bus bar in the electrical cabinet. If step-down transformer is supplied for operation, refer to instructions provided with the transformer.



*For safety during servicing, the power line must be connected to a main disconnect switch that can be locked in the off position or to a plug and receptacle that can be disconnected during servicing.*




*Do not provide power until preliminary installation is completed*

### Compressed Air connection

Clean and dry air is required.


Φ10 one touch female is located on the air panel at the backside of the laminator for connection of incoming air supply.

Check the air pressure gauge. Adjust the regulator following pressure to 0.55Mpa by knob.



**The exhaust from Vacuum pump**

The exhaust from vacuum pump should be connected to an external building exhaust line. Connect “Exhaust” fitting (G2”1/2 male)” to the building line with hose.








*Building exhaust line should be connected through the outlet hole with the proper diameter of exhaust line so that any access should not attempt through the gap.*

## 5. SYSTEM TOUR

The major components of the LAMINATOR MEGALAM are the vacuum chamber, pressure diaphragm, lamination platen, vacuum system, heating control system, chamber lifting system, PLC control system, loading/ unloading modules system. All of these systems are monitored and controlled by touch panel.

### 5.1 Vacuum chamber


The Vacuum chamber is two-piece clamshell design and is fabricated to withstand atmospheric pressure with minimum distortion. Chamber top is hinged to allow access for loading and unloading laminator. The two chamber halves are sealed with O-ring.



### 5.2 Pressure Diaphragm

A Diaphragm is used to apply lamination pressure to the module. The diaphragm is supported and sealed to the inside of the upper chamber by a clamping frame around its perimeter. The chamber volume below the diaphragm is called the lower chamber, while the volume above is called the lower chamber, while the volume above is called the upper chamber. Both chamber pressures are displayed on the touch panel.

The laminator will not operate properly if the diaphragm is punctured or its seal is broken. Replacement of the diaphragm is described in the section 'Maintenance and Troubleshooting'



### 5.3 Lamination Platen

The Lamination platen is the working surface of the laminator and its function is to support and heat the modules being processed. The platen consists of 5 plates connected together, electric heaters and thermocouples. The heaters are designed for long life. The top surface of the platen is covered with a Teflon release sheet so that any molten encapsulated material that extrudes from the edges of the module will not stick to the working surface.

The temperature control of the platen is divided into 3 independent separate control systems. Each platen is independently sensed and controlled. This is done to provide temperature uniformity.

Attached to the underside of each plate are thermocouple sensors, and a ground wire. The ground wires are a safety feature to prevent high voltage on the platen and to protect the operator from electrical hazard if there is an electrical short in the heater circuit. They must not.



***Do not remove the ground wire. 200 V is charged on the heater.***

***The operator loading a module into the platen may get an electrical shock by 200 voltage if the heater circuit has some problem.***


The platen contains 15 thermocouples for temperature control and uniformity. 3 thermocouples on each platen sense the platen temperature between each heater for controlling the platen temperature. These thermocouples provide platen temperature information to the temperature controllers, mounted in the electric cabinet. The other 3 thermocouples on each platen are used for monitoring unusual temperature and interlocking over heat.

The Lamination platen is supported off the Lower chamber floor by insulating bars to minimize



heat loss. This reduces the power consumption of the laminator and improves the temperature uniformity of the platen.

#### 5.4 Vacuum System (Option)

The vacuum system consists of vacuum pump, boosting blower, control valves, gauge. The Vacuum pump has the excellent performance with high-throughput and is located under the unloading conveyor. Use a high-performance valve for a vacuum for a vacuum circuit; of the omission of vacuum there is it in a plumbing part with extreme caution so that there is not it.





Two pressure sensors are equipped to measure the pressure in the upper and lower chamber. The measurement of the pressure sensors are displayed on the touch panel on the console.



#### 5.5. Main Heating control system

Platen Temperature is controlled by PLC. The actual temperature is sensed by thermocouples and it is continuously updated on the temperature screen.

Heaters are automatically regulated, as required, to obtain the desired temperature for any process ste. The PLC controls the temperature on 15 zones individually. In the 'Auto' mode, the temperature is controlled to the "pump" process setpoint when idling between process cycles. In the Manual mode the temperature is also maintained at the "Pump" process setpoint when the heaters are enabled. The heaters can be turned off by pressing the "Heater OFF" button on the "MANUAL" Screen.



### 5.5.1 Over-temperature Safety System

Each of the 5 platen is protected by an over-temperature alarm in its controller. The alarm setpoint is factory set to approximately 185°C, and must not be changed. When the over temperature setpoint is reached, the controller trips and interlock circuit, cutting power to all of the heaters. Cooling over temperature platens can reset this interlock circuit.




***Do not change the over-temperature setting.  
It may cause the serious machine trouble or the danger of fire in  
case of the unusual heat more than 200°C***

### 5.6 Chamber Lifting System

Four ball screw unit driven by an inverter controlled motor are used to raise and lower the upper chamber.

The positioning is controlled through the using encoder and PLC. After the main disconnect switch is on, the indexing movement ('Home') is necessary. The upper chamber has three height of position, "CLOSE", "MIDDLE" and "OPEN" and it is possible to position at any height as well.



To prevent injury to the operator, safety barrier and mechanical lock (Lock pins). If operator's body or other objects interrupt safety barriers (light curtains) the chamber will stop and alarm message will appear on the touch panel.

Lock pin is inserted in the disk linked with ball screw unit at cycle positions of the upper chamber stopped.


### 5.7 Lifting-up Pin

The Lifting-up pin the module during the pumping and separate the module from the platen to prevent the bow caused by the heat of the platen.

The lifting height is adjusted by the adjust screw on the cylinder.

### 5.8 Loading/ Unloading system

Automatic loading/ unloading conveyor are provided to make solar modules handling easily.



### 5.8.1 Loading conveyor

Conveyor Solar module will be set on the Loading conveyor and transferred to the laminator.


Photo-electric sensor is provided to detect misfeeding of the modules. If the sensor detects any object in the auto mode, PLC stop the upper chamber going down and the alarm message will appear on the touch panel.



Loading Conveyor

### 5.8.2 Conveyor in Laminator


The modules are transferred by thin Teflon sheet in the laminator. The sheet withstands over 200°C and its thickness is so thin not to spoil the vacuum in the chamber. Teflon sheet prevents EVA sticking on it as much as possible.



### 5.8.3 Unloading conveyor

Unloading conveyor consists of roller conveyor with silicon rubber rings.

The Teflon rubber rings withstand high-temperature modules and support them softly. Photo-electric sensor is provided to detect misfeeding of the modules. If the sensor detects any object in the auto mode, PLC stop the upper chamber going down and the alarm message will appear on the touch panel.



Belt


Control Box

**Unloading Conveyor**



## 6. CONSOLE DESCRIPTION

### 6.1 Console Monitor Consist



### 6.2 Console Button Description

- 1) 'Auto' button/light  
This button is to set the laminator in 'Automatic' mode.
- 2) 'Manual' button/light  
This button is to set the laminator in 'Manual' mode.
- 3) 'Start' button/light  
This button is to set the laminator in laminating cycle.
- 4) 'Stop' button/light  
This button is to stop the laminating cycle..
- 5) 'Control On': To operate 'Control system'
- 6) 'Control Off': To set off 'Control system'
- 7) 'Reset': To Reset 'Control system'
- 8) 'Heater': Heater ON/OFF select switch
- 9) 'Vacuum': Vacuum pump select switch
- 10) 'Spare': This button is to set when user required (Here is none)
- 11) 'E-Stop(Emergency Stop)' button  
When this button is pressed, all components in motion will stop immediately and power to the heaters and vacuum pump will be cut.

## 7. CONTROL PANEL OPERATING INSTRUCTION

### 7.1. 'Auto Mode Monitor' Window

This window monitors the conditions of the laminator components, parameter setting, and process..











Item	Definition	Note
TEMP	Turn on when platens temperature matches the automatic cycle start temperature.	Press the 'Confirm' button to proceed to the 'Pressure/Temperature' window.
RECIPE	The current selected program name	
TOP VACUUM	The current top chamber pressure is shown.	
BOTTOM VACUUM	The current bottom chamber pressure is shown.	
VACUUM	The light Turns on while vacuuming.	
PIN-UP	The light Turns on while PIN-UP	To prevent NG out-put with pin-up process

















SLOW PRESS	Turn on while pressing at slow speed.	Time : Set time and current time Pressure: Set pressure and current pressure of top chamber.
MID. PRESS	Turn on while pressing at middle speed.	Leak speed: Pressure increasing speed of previous / current cycle.
FAST PRESS	Turn on while pressing at high speed.	Temperature: Set temperature. You can select "Time" or "Pressure" on each process. The selected slot turns on.
HOLD PRESS	Turn on while holding Process	Time: The current time & Set time. Pressure: The current pressure of top chamber.
TOTAL	This button is shown the accumulated time in whole process.	The real time mark.
HYDRAULIC PUMP	To show the On/Off status of hydraulic pump	
VACUUM PUMP	To show the On/Off status of vacuum pump	

### 'Manual Operation' Window


This window controls the components of laminator by Manual. Before using this window, press 'Manual' button and check whether the red light to turn on.















Item	Description	Note
<b>TOP CHAMBER</b>		
	In/Out Cleaning brush of Loading Conveyor.	
	Closing/Opening leaning brush of Loading Conveyor.	
	Forwarding/reversing the direction of upper conveyor.	
	Operating /stopping the upper conveyor 1 time.	
	On/ Off vacuuming system operating in top chamber	
	On/ Off Ventilation system operating in top chamber	After operating vacuum button off
	Open/Close valve in process of Slow Press	

		Open/Close valve in process of MID Press	
		Open/Close valve in process of Fast Press	
<b>BOTTOM CHAMBER</b>			
		Falling/Raising Pin Plate.	
		On/ Off vacuuming system operating in bottom chamber	
		On/ Off vacuuming system operating in bottom chamber	After operating vacuum button off
		On/ Off boosting for the vacuuming	To support vacuum system, if possible
		Out/In Cleaning brush.	
		Operating/Stopping Cleaning brush.	

## 7.2. 'Module Operating 2' Window







Item	Description	Note
<b>CHAMBER</b>		
	To raise the upper chamber for maximum height.	
	To raise the upper chamber for middle height.	
	To raise the upper chamber for replacing Diaphragm to appropriate height.	
	The laminating position where the top chamber to have connection with the bottom chamber.	
	Closing/Opening the upper chamber by manual.	Operate while pressing.
<b>DELIVERY CONVEYOR</b>		
	To jog compressor conveyor for forward/backward movement.	Operate while pressing.

	On/Off the cooling fan under the Delivery conveyor	
<b>BOTTOM SHEET</b>		
	Move the lower conveyor backward	Operate while pressing.
	Move the lower conveyor One rounding.	One-press for one-round.
<b>ENTRY CONVEYOR</b>		
	Move loading conveyor to forward/backward movement.	
	Continuous Move the lower conveyor and compressed conveyor for one time	
	Continuous Move the lower conveyor compressed conveyor for one time.	

### 7.3. 'Temperature Inspection' Window









Item	Definition	Note
<b>PLATE #1 / PLATE #2 / PLATE #3 / PLATE #4 / PLATE #5</b>		
	To show the current temperature	
 	To show the heater on/off.	
	To show the heater when to reach set temperature and range.	



### 7.4. 'Reading Information' Window



Item	Definition	Note
	To show the stored description.	
	Order numbering	
	To bring memorized recipe from No. or Description	Meaning of 'from'
	To put memorized recipe to No. or Description	Meaning of 'to'
	To copy memorized recipe to No. or Description	
	To retrieve the needed recipe for the stored description.	

### 7.5. 'PARAMETER(Details of each recipe)' Window

LAM-2246		PARAMETER		19-09-11 14:54													
RECIPE NO.		23	ABCDEFGHIJKL														
PROCESS MODE		<input type="checkbox"/> TIME Priority <input checked="" type="checkbox"/> PRESSURE Priority	<table border="1"> <thead> <tr> <th colspan="2">TEMPERATURE SETTING</th> </tr> </thead> <tbody> <tr> <td>HOT PLATE-1</td> <td>456 °C</td> </tr> <tr> <td>HOT PLATE-2</td> <td>456 °C</td> </tr> <tr> <td>HOT PLATE-3</td> <td>456 °C</td> </tr> <tr> <td>HOT PLATE-4</td> <td>456 °C</td> </tr> <tr> <td>HOT PLATE-5</td> <td>456 °C</td> </tr> </tbody> </table>			TEMPERATURE SETTING		HOT PLATE-1	456 °C	HOT PLATE-2	456 °C	HOT PLATE-3	456 °C	HOT PLATE-4	456 °C	HOT PLATE-5	456 °C
TEMPERATURE SETTING																	
HOT PLATE-1	456 °C																
HOT PLATE-2	456 °C																
HOT PLATE-3	456 °C																
HOT PLATE-4	456 °C																
HOT PLATE-5	456 °C																
VACUUM TIME	VACUUM	56 m 56 s															
	PIN-UP	56 m 56 s															
SLOW PRESSURE		56 m 56 s	456 kPa														
MIDDLE PRESSURE		56 m 56 s	456 kPa														
FAST PRESSURE		56 m 56 s	456 kPa														
HOLDING PRESSURE		56 m 56 s															
TOTAL		56 m 56 s															
<input type="button" value="SAVE"/>																	
<input type="button" value="AUTO"/>		<input type="button" value="MANUAL1"/>	<input type="button" value="MANUAL2"/>	<input type="button" value="TEMP"/>	<input type="button" value="RECIPE"/>												
		<input type="button" value="PARA-METER"/>	<input type="button" value="SYSTEM SET"/>	<input type="button" value="AUTO TUNNING"/>	<input type="button" value="ALARM"/>												
		<input type="button" value="I/O MONITOR"/>															

Item	Definition	Note			
<input type="button" value="SLOW PRESSURE"/>	To set the slow pressing time and pressure.				
<input type="button" value="MIDDLE PRESSURE"/>	To set the mid pressing time and pressure.				
<input type="button" value="FAST PRESSURE"/>	To set the fast pressing time and pressure.				
<input type="button" value="HOLDING PRESSURE"/>	To set the elapsed time for holding.				
<input type="button" value="RECIPE NO."/>	Number and name of the operating recipe				
<input type="button" value="PROCESS MODE"/>	To choose the priority process				
<input type="button" value="SAVE"/>	Push to save the information as shown				
<table border="1"> <tr> <td rowspan="2">VACUUM TIME</td> <td>VACUUM</td> </tr> <tr> <td>PIN-UP</td> </tr> </table>	VACUUM TIME	VACUUM	PIN-UP	To set the vacuum and pin-up time	
VACUUM TIME		VACUUM			
	PIN-UP				
<input type="button" value="TEMPERATURE SETTING"/>	To set the temperature of each heating plate				

### 7.6. ' Auto Tuning ' Window

This window shows to control heating plate (#1 ~ #5) of laminator and the basic parameter for alarm.

<b>NOTICE</b>	<p>This page is to initialize the control system. All parameters are set at the manufacture's factory for optimum performance. Do not attempt to change any parameters without an advice from manufacture.</p>
---------------	--

LAM-2246	AUTO TUNNING									19-09-11 14:54
ITEM	1-1 HEATER	1-2 HEATER	1-3 HEATER	2-1 HEATER	2-2 HEATER	2-3 HEATER	3-1 HEATER	3-2 HEATER	3-3 HEATER	
SV	123 °C			123 °C			123 °C			
PV	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	
P	1234 X	1234 X	1234 X	1234 X	1234 X	1234 X	1234 X	1234 X	1234 X	
I	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	
D	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s	
CYCLE TIME	234 s	234 s	234 s	234 s	234 s	234 s	234 s	234 s	234 s	
ALARM TEMP	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	
OFFSET	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C	
AUTO TUNNING	On	On	On	On	On	On	On	On	On	
ITEM	4-1 HEATER	4-2 HEATER	4-3 HEATER	5-1 HEATER	5-2 HEATER	5-3 HEATER				
SV	123 °C			123 °C						
PV	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C				
P	1234 X	1234 X	1234 X	1234 X	1234 X	1234 X				
I	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s				
D	1234 s	1234 s	1234 s	1234 s	1234 s	1234 s				
CYCLE TIME	234 s	234 s	234 s	234 s	234 s	234 s				
ALARM TEMP	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C				
OFFSET	234 °C	234 °C	234 °C	234 °C	234 °C	234 °C				
AUTO TUNNING	On	On	On	On	On	On				
<div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span style="background-color: #0070C0; color: white; padding: 5px 20px; border: 1px solid black;">AUTO TUNNING RUN</span> <span style="background-color: #0070C0; color: white; padding: 5px 10px; border: 1px solid black;">SAVE</span> <span style="background-color: #800000; color: white; padding: 5px 10px; border: 1px solid black;">CANCEL</span> </div>										
AUTO	MANUAL1	MANUAL2	TEMP	RECIPE	PARA-METER	SYSTEM SET	AUTO TUNNING	ALARM HISTORY	I/O MONITOR	

### 7.7. 'SYSTEM SET' Window

LAM-2246		SYSTEM SET		19-09-11 14:54	
ENTRY CONVEYOR START TIME	345.6 sec				
ENTRY CONVEYOR 1 PITCH TIME	345.6 sec				
DELIVERY CONVEYOR STOP TIME	234.5 sec				
DELIVERY CONVEYOR COOLING TIME	123 min				
TOP CHAMBER VACUUM PRESSURE	123 kPa				
TOP CHAMBER VENT PRESSURE	123 kPa				
BOTTOM CHAMBER VENT PRESSURE	123 kPa				
VACUUM BOOSTER STARTING PRESSURE	123 kPa				

Item	Definition	Note
ENTRY CONVEYOR START TIME	To set the loading time of entry conveyor.	
ENTRY CONVEYOR 1 PITCH TIME	To set the loading time of entry conveyor for 1 pitch.	
DELIVERY CONVEYOR STOP TIME	To set the stopping time of delivery conveyor.	
DELIVERY CONVEYOR COOLING TIME	To set the cooling time for laminated module.	
TOP CHAMBER VACUUM PRESSURE	To set the strength of vacuum pressure of top chamber	
TOP CHAMBER VENT PRESSURE	To set the strength of VENT pressure of top chamber	
BOTTOM CHAMBER VENT PRESSURE	To set the strength of VENT pressure of bottom chamber	
VACUUM BOOSTER STARTING PRESSURE	To set the starting power of vacuum booster.	

### 7.8. 'ALARM' Window










LAM-2246		ALARM HISTORY		19-09-11 14:54	
OCCURRED	MESSAGE	REST .	CHECK		
11/09/19 14:54:26		14:54	14:54		
11/09/19 14:54:26	HEATER 1-1 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 1-2 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 1-3 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 2-1 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 2-2 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 2-3 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 3-1 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 3-2 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 3-3 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 4-1 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 4-2 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 4-3 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 5-1 OUT// CHECK CURRENT & VOLUME	14:54	14:54		
11/09/19 14:54:26	HEATER 5-2 OUT// CHECK CURRENT & VOLUME	14:54	14:54		

Cursor ON	Up	Check	Delete
Cursor OFF	Down	Check all	Delete all

AUTO	MANUAL1	MANUAL2	TEMP	RECIPE	PARA-METER	SYSTEM SET	AUTO TUNNING	ALARM	I/O MONITOR
------	---------	---------	------	--------	------------	------------	--------------	-------	-------------


Item	Definition	Note
 	To appear the cursor to check errors	
 	To move the cursor up and down movement.	
 	To check the recognized time by operator	
	To check the time to solve the problem	
 	To delete the one or all error history	

## 7.9. 'I/O MONITOR' Window

### 7.9.1 I/O MONITOR-1(input monitor)

LAM-2246		I/O MONITOR-1		HINT	19-09-11 14:54
<input type="checkbox"/> X100 [SS] AUTO MODE	<input type="checkbox"/> X120 [MC] HYD. PUMP RUN	<input type="checkbox"/> X140 [PB] ENTRY CONV. 1 PITCH	<input type="checkbox"/> X160 [PB] DELIVERY CONV. 1 PITCH		
<input type="checkbox"/> X101 [PB] START	<input type="checkbox"/> X121 [MC] COOLING FAN RUN	<input type="checkbox"/> X141 [PB] ENTRY CONV. FINISH	<input type="checkbox"/> X161 [PB] DELIVERY CONV. FINISH		
<input type="checkbox"/> X102 [PB] STOP	<input type="checkbox"/> X122 [MC] HEATER TURNED-ON	<input type="checkbox"/> X142 [PB] ENTRY CONV. E-STOP	<input type="checkbox"/> X162 [PB] DELIVERY CONV. E-STOP		
<input type="checkbox"/> X103 [SS] HEATER TURN-ON	<input type="checkbox"/> X123 [MC] INV. TURNED-ON	<input type="checkbox"/> X143 [PH] ENTRY CONV. GLASS IN	<input type="checkbox"/> X163 [PB] DEL. CONV. GLASS OUT		
<input type="checkbox"/> X104 [SS] VAC. PUMP TURN-ON	<input type="checkbox"/> X124 [MC] VAC. PUMP RUN	<input type="checkbox"/> X144 [PH] ENTRY CONV. GLASS OUT	<input type="checkbox"/> X164 [PR] MIAN AIR PRESSURE O.K		
<input type="checkbox"/> X105 [SS] HYD. PUMP TURN-ON	<input type="checkbox"/> X125 [MC] CHILLER RUN	<input type="checkbox"/> X145 [PH] ENTRY AREA SAFETY	<input type="checkbox"/> X165 [CS] DELIVERY PIN TOP		
<input type="checkbox"/> X106 [PB] RESET	<input type="checkbox"/> X126 [INV] ENTRY CONV. OL.	<input type="checkbox"/> X146 [PH] FORNT AREA SAFETY	<input type="checkbox"/> X166 [CS] DELIVERY PIN BOTTOM		
<input type="checkbox"/> X107	<input type="checkbox"/> X127 [EOCR] HYD. PUMP OL.	<input type="checkbox"/> X147 [PH] DELIVERY AREA SAFETY	<input type="checkbox"/> X167		
<input type="checkbox"/> X108 [PB] SPARE-1	<input type="checkbox"/> X128 [INV] TOP SHEET OL.	<input type="checkbox"/> X148	<input type="checkbox"/> X168		
<input type="checkbox"/> X109 [PB] SPARE-2	<input type="checkbox"/> X129 [INV] ENTRY BRUSH OL.	<input type="checkbox"/> X149 [CS] ENTRY PIN TOP	<input type="checkbox"/> X169		
<input type="checkbox"/> X10A	<input type="checkbox"/> X12A	<input type="checkbox"/> X14A [CS] ENTRY PIN BOTTOM	<input type="checkbox"/> X16A		
<input type="checkbox"/> X10B	<input type="checkbox"/> X12B [INV] BOTTOM SHEET OL.	<input type="checkbox"/> X14B	<input type="checkbox"/> X16B [PX] DEL. CHAMBER TOP		
<input type="checkbox"/> X10C	<input type="checkbox"/> X12C [INV] DELIVERY BRUSH OL.	<input type="checkbox"/> X14C	<input type="checkbox"/> X16C		
<input type="checkbox"/> X10D	<input type="checkbox"/> X12D [INV] DELIVERY CONV. OL.	<input type="checkbox"/> X14D [PX] CHAMBER TOP	<input type="checkbox"/> X16D [PX] DEL. CHAMBER BOTTOM		
<input type="checkbox"/> X10E	<input type="checkbox"/> X12E [EOCR] VAC. PUMP OL.	<input type="checkbox"/> X14E [PX] CHAMBER MIDDLE	<input type="checkbox"/> X16E		
<input type="checkbox"/> X10F	<input type="checkbox"/> X12F [EOCR] CHILLER OL.	<input type="checkbox"/> X14F [PX] CHAMBER RUBBER	<input type="checkbox"/> X16F		
	<input type="checkbox"/> X130 [TC] HEAT PLATE-1 OT.	<input type="checkbox"/> X150 [PX] CHAMBER BOTTOM	<input type="checkbox"/> X170		
	<input type="checkbox"/> X131 [TC] HEAT PLATE-2 OT.	<input type="checkbox"/> X151	<input type="checkbox"/> X171		
	<input type="checkbox"/> X132 [TC] HEAT PLATE-3 OT.	<input type="checkbox"/> X152 [PX] TOP SHEET FWD. OVER	<input type="checkbox"/> X172		
	<input type="checkbox"/> X133 [TC] HEAT PLATE-4 OT.	<input type="checkbox"/> X153 [PX] TOP SHEET FWD. STOP	<input type="checkbox"/> X173		
	<input type="checkbox"/> X134 [TC] HEAT PLATE-5 OT.	<input type="checkbox"/> X154 [PX] TOP SHEET FWD. SLOW	<input type="checkbox"/> X174		
	<input type="checkbox"/> X135	<input type="checkbox"/> X155 [PX] TOP SHEET REV. SLOW	<input type="checkbox"/> X175		
	<input type="checkbox"/> X136	<input type="checkbox"/> X156 [PX] TOP SHEET REV. STOP	<input type="checkbox"/> X176		
	<input type="checkbox"/> X137	<input type="checkbox"/> X157 [PX] TOP SHEET REV. OVER	<input type="checkbox"/> X177		
	<input type="checkbox"/> X138	<input type="checkbox"/> X158 [CS] ENTRY BRUSH IN	<input type="checkbox"/> X178 U-I/F IN-1 (RECEIVE POSSIBLE)		
	<input type="checkbox"/> X139	<input type="checkbox"/> X159 [CS] ENTRY BRUSH OUT	<input type="checkbox"/> X179 U-I/F IN-2 (RECEIVE READY)		
	<input type="checkbox"/> X13A	<input type="checkbox"/> X16A [PX] BOTTOM SHEET OVER	<input type="checkbox"/> X17A U-I/F IN-3 (RECEIVE COMPLETE)		
	<input type="checkbox"/> X13B	<input type="checkbox"/> X16B [PX] BOTTOM SHEET STOP	<input type="checkbox"/> X17B U-I/F IN-4		
	<input type="checkbox"/> X13C	<input type="checkbox"/> X16C [PX] BOTTOM SHEET SLOW	<input type="checkbox"/> X17C D-I/F IN-1 (RECEIVE POSSIBLE)		
	<input type="checkbox"/> X13D	<input type="checkbox"/> X16D [CS] DELIVERY BRUSH IN	<input type="checkbox"/> X17D D-I/F IN-2 (RECEIVE READY)		
	<input type="checkbox"/> X13E	<input type="checkbox"/> X16E [CS] DELIVERY BRUSH OUT	<input type="checkbox"/> X17E D-I/F IN-3 (RECEIVE COMPLETE)		
	<input type="checkbox"/> X13F [PR] HYD. PRESSURE	<input type="checkbox"/> X16F [LS] SAFETY BAR	<input type="checkbox"/> X17F D-I/F IN-4		

AUTO MANUAL1 MANUAL2 TEMP RECIPE PARA-METER SYSTEM SET AUTO TUNNING ALARM TO OUTPUT MONITOR

To put the switch,  the Hint of initial should be appeared as below:


**HINT for INPUT MONITOR !** X

[SS]: SELECTOR SWITCH  
 [PB]: PUSH BUTTON SWITCH  
 [MC]: MAGNETIC CONTACTOR  
 [INV]: INVERTER FOR MOTOR  
 [EOCR]: ELECTRIC OVER CURRENT RELAY  
 [TC]: THERMO CONTROLLER  
 [PR]: PRESSURE DETECT SENSOR  
 [PH]: PHOTO BEAM SENSOR  
 [CS]: CYLINDER SENSOR  
 [PX]: PROXIMITY SENSOR  
 [LS]: LIMIT SENSOR

## 7.9.2 I/O MONITOR-2(Output monitor)

LAM-2246		I/O MONITOR-2		HINT		19-09-11 14:54	
Y200	[PBL] START	Y220	[INV1] ENTRY CONV. FWD.	Y240	[PBL] ENTRY CONV. 1 PITCH	Y260	[PBL] ENTRY CONV. 1 PITCH
Y201	[PBL] STOP	Y221	[INV1] ENTRY CONV. REV.	Y241	[PBL] ENTRY CONV. FINISH	Y261	[PBL] ENTRY CONV. FINISH
Y202	[PL] TOWER-RED	Y222	[INV1] ENTRY CONV. RM	Y242	[CR1] HYD. PUMP TURN-ON	Y262	[PBL] DELIVERY CONV. 1 PITCH
Y204	[PL] TOWER-YELLOW	Y223	[INV1] ENTRY CONV. RH	Y243	[CR2] VACUUM PUMP TURN-ON	Y263	[PBL] DELIVERY CONV. FINISH
Y205	[PL] TOWER-GREEN	Y224	[INV1] ENTRY CONV. RESET	Y244	[CR3] CHILLER TURN-ON	Y264	[PSOL] ENTRY PIN UP
Y206	[BZ] MELODY-1	Y225	[CR6] CHAMBER OPEN	Y245	[CR4] COOLING FAN TURN-ON	Y265	[PSOL] DELIVERY PIN DOWN
Y207	[BZ] MELODY-2	Y226	[CR7] CHAMBER CLOSE	Y246		Y266	[PSOL] ENTRY BRUSH IN
Y208	[BZ] MELODY-3	Y227	[CR8] CHAMBER SLOW	Y247		Y26A	[PSOL] DELIVERY BRUSH IN
Y209	[BZ] MELODY-4	Y228	[INV2] TOP SHEET FWD.	Y248		Y26C	[PSOL] TOP VACUUM TURN-ON
Y20A	[PL] AIR PRESSURE O.K	Y22A	[INV2] TOP SHEET REV.	Y249		Y26D	[PSOL] SLOW PRESS TURN-ON
Y20B	[PL] HEATER TURNED-ON	Y22B	[INV2] TOP SHEET RM	Y24A		Y26E	[PSOL] MIDDLE PRESS TURN-ON
Y20C	[PL]	Y22C	[INV2] TOP SHEET RH	Y24B		Y26F	[PSOL] FAST PRESS TURN-ON
Y20D	[PL] PIN-TOP	Y22D	[INV2] TOP SHEET RESET	Y24C		Y270	[PSOL] TOP VENT TURN-ON
Y20E	[PL] VACUUM PRESSURE O.K	Y22E	[INV3] ENTRY BRUSH FWD.	Y24E		Y271	[PSOL] BOTTOM VAC. TURN-ON
Y20F	[PL] SLOW PRESSING	Y22F	[INV3] ENTRY BRUSH REV.	Y24F		Y272	[PSOL] BOTTOM VENT TURN-ON
Y210	[PL] MIDDLE PRESSING	Y230	[INV3] ENTRY BRUSH RESET	Y250		Y273	
Y211	[PL] FAST PRESSING	Y231		Y251		Y274	
Y212	[PL] HOLD PRESSING	Y232		Y252		Y275	
Y213		Y233		Y253		Y276	
Y214		Y234		Y254		Y277	
Y215		Y235	[INV4] BOTTOM SHEET FWD.	Y255		Y278	U-I/F OUT-1 (SEND REQUEST)
Y216		Y236	[INV4] BOTTOM SHEET REV.	Y256		Y279	U-I/F OUT-2 (SEND READY)
Y217		Y237	[INV4] BOTTOM SHEET RM	Y257		Y27A	U-I/F OUT-3 (SEND COMPLETE)
Y218		Y238	[INV4] BOTTOM SHEET RESET	Y258		Y27B	U-I/F OUT-4
Y219		Y239	[INV5] DELIVERY BRUSH FWD.	Y259		Y27C	D-I/F OUT-1 (SEND REQUEST)
Y21A		Y23A	[INV5] DELIVERY BRUSH REV.	Y25A		Y27D	D-I/F OUT-2 (SEND READY)
Y21B		Y23B	[INV5] DELIVERY BRUSH RESET	Y25B		Y27E	D-I/F OUT-3 (SEND COMPLETE)
Y21C		Y23C	[INV6] DELIVERY CONV. FWD.	Y25C		Y27F	D-I/F OUT-4
Y21D	[PBL] RESET	Y23D	[INV6] DELIVERY CONV. REV.	Y25D			
Y21E	[PBL] SPARE-1	Y23E	[INV6] DELIVERY CONV. RM	Y25E			
Y21F	[PBL] SPARE-2	Y23F	[INV6] DELIVERY CONV. RESET	Y25F			

AUTO   MANUAL1   MANUAL2   TEMP   RECIPE   PARA-METER   SYSTEM SET   AUTO TUNNING   ALARM   TO INPUT MONITOR

To put the switch,  the Hint of initial should be appeared as below:

HINT for OUTPUT MONITOR ! X

[[PBL]: PUSH BUTTON WITH LIGHT  
 [PL]: PILOT LAMP  
 [BZ]: SIGNAL PHONE  
 [INVx]: INVERTER FOR MOTOR (x: no.)  
 [CRx]: COIL of RELAY (x: no.)  
 [PSOL]: PNEUMATIC SOLENOID VALVE  
 [HSOL]: HYDRAULIC SOLENOID VALVE

## 8. Operating Instruction

### 8.1. Start-up Operation



*Prior to operate the Laminator, be sure the following checkpoints have been confirmed.*


- 1. Be sure all personnel are clear of the machine.*
- 2. Verify external power source is in 'on' position.*
- 3. Be sure compressed air line is activated.*
- 4. All doors must be closed.*
- 5. Operator has the proper protective such as gloves.*




*Never operate the Laminator with Electric cabinet door opened.  
High voltages can be present in the box that can cause personal injury or death when the power is on.*




1. Turn on the main disconnect switch on the electric cabinet and 'POWER' light turn on the console.



2. Press the 'POWER ON' button on the console stand.

	<p>The touch panel screen on the console stand will be activated.</p>
--	---

3. Ensure that the emergency stop (E-Stop) button is in the out position.

	<p>The Laminator has an emergency stop circuit that must be reset before the Laminator will work.</p> <p>To set the E-Stop button in the out position, turn the button in the direction of the arrow.</p>
---	---

## 8.2. Presetting Prior to Laminating execution

### 8.3. Warm up the Platens

The red light will turn on and the 2 heating control system (laminator and loading conveyor platens) will be activated.

The “Heating Complete” will turn on when the platen temperature reaches the temperature setting. All platen must be turn on the button of “Heating Completed”.




Press the key of the arrow in the right upper Loading C/V for Loading C/V temperature.

The “Heating Complete” will turn on, when the platen temperature reaches the temperature setting. All platen must be turn on the button of ‘Heating Completed’

### 8.4. Auto mode

1. If press the 'AUTO' button on the console stand. The green light should turn on.  
The heater control system starts platen temperature control..



LAM-2246		AUTO OPERATION				19-09-11 14:54			
RECIPE	23	ABCDEFGHIJKL	TOP VACUUM	123 kPa	BOTTOM VACUUM	789.456 kPa			
CHAMBER POSITION	T	M	R	B	TEMP	123 °C	HEAT-UP COMPLETE		
HYDRAULIC PUMP	ON	OFF	VACUUM PUMP	ON	OFF	AUTO-RUN CONDITION			
SET TIME	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s		
PRESENT TIME	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s	12 m 12 s		
100%									
50%									
0%									
PRESENT	VACUUM	PIN-UP	SLOW PRESS	MID. PRESS	FAST PRESS	HOLD PRESS	TOTAL		
11/09/19 14:54:15							↑	↓	
AUTO	MANUAL1	MANUAL2	TEMP	RECIPE	PARA-METER	SYSTEM SET	AUTO TUNNING	ALARM HISTORY	IO MONITOR

In the 'Auto mode monitor" window, the platen(Laminator) completed 'light turns on if the platen temperature matches the target of the setpoint temperature in 'Pump' process.

In loading conveyor, the platen completed 'light turns on If the platen temperature matches the target of setpoint temperature in 'Preheating on C/V'

The 'Home Positions' light in the 'Auto mode monitor' window will turn on when laminating.

### 8.5. Automatic Batch Mode: 1 Cycle Automatic Mode

1. Press '1 Batch' button in the 'Auto mode monitor' window
2. Load the stack of module materials on the platen in the laminator. Be sure the stack is positioned inside the effective lamination area.



***The laminating platen may be extremely hot.***

***Heavy cotton or other thermally insulation gloves must be worn to protect the hands from burns.***

3. Cover the module stack with a release Teflon sheet to prevent EVA encapsulant from adhering to the diaphragm.
4. Press the 'START' button on the console stand. The green light will turn on and automatic cycle will start. The upper camber will close down automatically.



***The upper chamber is heavy and can cause personnel injury.***


***Be sure all personnel are clear of the machine when starts automatic.***

#### 5. Automatic Laminating

While the automatic laminating, The procedure of 'Auto monitor' can be checked in the monitor. The execution process button turns on, the process time, current temperature and vacuum pressure will be updated in the window.

6. Finishing Lamination and unloading the processed module.

When the automatic lamination finished, the upper chamber opens automatically. The laminated module and release sheet can be removed from the laminator.



***The lamination platen may be extremely hot. When unloading the encapsulated module, heavy cotton or other thermally insulation gloves must be worn to protect the hands from burns.***

### 8.6. Automatic Laminating (Automatic Mode)

1. Press the start button 'Auto mode monitor'.




2. The green light will turn on and automatic cycle will start.
3. Load the stack of module materials on the platen in the laminator. Be sure the stack is positioned inside the effective lamination area.




***The laminating platen may be extremely hot.  
Heavy cotton or other thermally insulation gloves must be worn to protect the hands from burns.***

4. Cover the module stack with a release sheet Teflon sheet to prevent EVA encapsulant from adhering to the diaphragm.
5. Press the '1 pitch' button on the console stand, Be sure the stack is positioned inside the effective lamination area.



Conveyor will transfer for the time which is set in the process parameter until the module hits the loading position sensor.

### 8.7. Work set completed



1. “Compressor work finish” button will turn on the light when the loading position sensor detects the module.
2. Cover the release sheet and press Release sheet “Compressor work finish”.
3. When Press ‘Compressor work finish’ button and conveyor sends the module to the loading position with slow speed, The lamp will change from flashing to lighting.
4. Module is automatically loaded from conveyor into inside of laminator, when the following condition is satisfied..
  - ① Temperature sensor on loading conveyor reached the set temperature for ‘starting temperature’
5. The upper chamber will close down automatically and automatic encapsulation starts.
6. When the automatic encapsulation is finished, the upper chamber opens automatically. The encapsulated modules are loaded from laminator to unloading conveyor.
7. Remove ‘release sheet’
8. Press the ‘Compressor work finish’ button. The module is loaded automatically from loading conveyor to downstream conveyor.

## 9. ALARM

### 9.1. Alarm Message

When an alarm occurs, the laminator is notified to an operator through the below devices.

1. Signal tower in AC-box
2. Music Horn
3. The alarm message in the touch panel.

### 9.2. Signal Tower

A Signal tower is located on the distribution box. The signal means as the below.

Red : The laminator is under warning condition.

Yellow: Being covered by Safety wall.

Blue: The laminator is in the automatic laminating.

### 9.3. Signal Tower

Signal horn speaker in AC-box notifies the operator to be under warning & alert.

#### 9.3.1 How to reset the alarm

When the alarm occurs while automatic laminating.

- A. The red light Signal of the signal tower flashes or light.
- B. The alarm history is recorded with appearing 'Alarm' window on the touch panel.

### 9.4. Resetting automatic laminating

If the 'START' button on the console stand is flashing, the automatic laminating can reset from interrupt process. Press the 'START' button.

If the 'START' button is not flashing, the automatic laminating cannot reset. In case, unload the stack of the module from the laminator and do 'Home' procedure.



## 10. MAINTENANCE

### Preventive maintenance list

Item	Action	Frequency	Record/ Notes
<b>Safety device</b>			
Light curtain	Check	Everyday	Proper working
Overheat protection	Check	Everyday	Set 185°C
Lock pin For Chamber lifter	Check	Everyday	Lock pin is inserted to hold lifting arm.
<b>Vacuum Pump(Leybold SV300B)</b>			
Oil Height	Check & Supplement	Everyday	The middle range of gauge
Oil Condition	Check	Everyday	No dark brown and black
Oil Change	Exchange	Every 1-month	Quick Exchange depends on materials.
Oil Filter	Exchange	Every 2-month	
Inspection for pump	Close Inspection	Every 6-month	
<b>LAMINATOR</b>			
Chamber O Ring	Check & Clean	Everyday	
Upper release sheet	Checking & Clean	Everyday	
Conveyor sheet	Check & Cleaning check	Everyday	
Diaphragm for Punctures	Check	Every 1-month	
Leak speed Press1~3	Record	Every 1-month	Leak Time: Press1= Kpa/sec Press2= Kpa/sec Press3= Kpa/sec
Lower chamber Vacuum	Record	Every 1-month	Min. Pressure = Pa
Platen temperature uniformity	Record	Every 1-month	±2°C
Vacuum hose	Check	Every 1-month	Visual check for damage for deformation



Heating speed	Check	Every 12-month	= min(50=>130°C)
<b>COMPRESSED AIR UNIT</b>			
Air Pressure Regulator	Check	Everyday	Pressure> 0.5 MPa
Water Separator	Check	Every one month	Drain the liquid by pressing
<b>Vacuum Pump (Leybold WAU501)</b>			
Oil height	Check & Supplement	Everyday	The middle range of gauge
Oil condition	Check	Everyday	No dark brown and black
Oil exchange	Exchange	Every one month	Quick Exchange depends on materials.
Inspection	Close Inspection	Every 6-month	
<b>Oil filter (This device not provided in this equipment)</b>			
Pressure gauge	Check	Everyday	Check the power on. Not too low and too high
Oil height	Check	Everyday	Check the oil height on vacuum pump.
Oil condition	Check	Everyday	No dark brown and black
hose	Check	Everyday	Visual check for damage for deformation



***The main breaker needs to be turned off prior to any type of maintenance work..***



***The operator is not allowed to service the machine with door key.  
All the key for any doors or switches needs to be under control of supervisor only.  
Do not open the door electric cabinet with power on.  
There is a danger to get the electrical shock on the hot circuit with dangerous voltage in the door.  
Turn off the main breaker, ELB0, prior to any type of maintenance work with the doors open.***



***Never touch the following circuits. Incoming terminals on ELB0, Circuit protector CP0 and lamp PLO0, those are hot even after the main breaker is turned off.***  
***There is danger to get electrical shock on those.***

## **10.1 Safety System**

### **10.1.1 Safety Barrier System**

The safety barrier system and the warning signal should be checked for proper operation. The upper chamber movement should be allowed only when the safety barriers are not interrupted. Interrupt the safety barriers by some kind of object (Not Hand) while the upper chamber is rising and/or closing, check the chamber movement is stopped and alarm message appear on the touch panel.



***Never put your hand inside the Safety barrier while the upper chamber is closing.***

### **10.1.2 Over-temperature Control System**


The Thermocouple meters provide protection to the laminator in the event of a failure in the main control system, which results in excess heating of the lamination platen. The meter set point should normally be set to 185°C.



***The electronic panel contains high voltage wiring and can cause serious personal injury.***

### **10.1.3 Safety Pole**

Safety pole must be set in the corners of the chamber during maintenance of platens or release sheet. Limit switches detect that the safety poles are set in the hunger. If one of the switches turned off, all control system is shut off in the same condition as emergency stop.




### 10.2.1 Vacuum Pump(Optional)



*The vacuum pump gets hot over 80°C and oil in the pump gets extremely hot.  
These may cause the injury.*

*You should make sure to stop the pump operation and wait long enough until the pump gets cool down before you start the maintenance work.*

### 10.2.2 Vacuum Pump SV300B(Optional)



### **10.2.3 Check Oil Height (Option)**

The pump oil height must be in the middle of oil-level glass during operating. If necessary, the pump switch turns off, supply the exact quantity of oil. Over supplying is brought oil loss, because of high suction.

The oil height must be checked every day.

### **10.2.4 Check Oil Condition (Option)**

Typically, Oil is colorless light brown. If the color of oil is black or dark brown, it must be changed.

If the dissolved gas or liquid in oil cause to decline the final pressure, Oil can be removed from pump by closing the suction port for 30-minute and opening the gas ballast valve.

For adjustment of the needed quantity, Oil can be drained out into a breaker or a small bowl under turning off and keeping the operating temperature.

### **10.2.5 Oil exchange (Option)**

All the times, The oil must be exchanged under pump turn-off and keeping the operating temperature.

If there is the polymerized danger by the connected process, the prompt exchange must be after pump operating.

Release the Oil-drain-plug and Drain out the used oil into the proper container, when to treat with the used oil, the relevant environmental regulations must be observed.

When the speed of oil leak is slow, fasten oil-drain-plug, turn on (for max. 10-second) the pump and turn off for a while. Remove the oil-drain-plug again and then Drain out the rest of oil.

### **10.2.5 Oil filter replacement (Option)**

Release the oil filter

Bring the new oil filter

Wet the gasket with the oil and then fasten the screw.

Insert the oil-drain plug again.

Release the oil-drain plug, the new oil must be topped up by the lower edge of the oil level glass.

Operate the pump for a while and then exchange the oil.

Make sure the proper oil.

### **10.2.6 Oil Filter Exchange (Option)**

The oil filter is for taking off the pollutant..

The exchange time is one time oil filter in two times oil exchange.

If the oil filter is blocked, the pollutant occurs inside of the oil and the oil leakage.

A general filter automobile is available.

1. Remove the oil filter after draining out from the vacuum pump.
2. After inserting the oil filter, fasten tightly. It cause to leak, do not too much tight.

### **10.2.7 Pump Close Inspection (Option)**

It is necessary that the vacuum pump is inspected in the case of the below. To avoid unexpected problems such as stopping. The regular inspection is recommended in every 6-month.

1. Although no breakdown diaphragm or heater hose. The vacuum does not reached to 150 Pa.
2. If the pump is covered like noise from pump, open the Noise box (The breakage may be inside of wing) Stop operating immediately, if not, It cause to the serious damage in pump.
3. After the oil exchange, Oil is quickly contaminated, which proves that the bad quality of oil is still left in circulation system, it cause to clog and overload.
4. The circuit breaker works by overloading. (The circuit breaker can be used by resetting, but the pump inspection is strongly recommended)

### **10.2.8 Wiring and Direction of Rotation (Option)**


To prepare for the motor changing, The labels of 'U1A', 'V1A', 'W1A' is on the terminal, even on the motor, in which must be maintained the same wiring.

1. Turn on the machine and ready.
2. Turn on the motor for 3-second, turn off and then see the rotating direction of the fan.
3. The direction of the rotation must be same the arrow direction.
4. If not, turn off both the motor and the main breaker of the machine, wire again.

### **10. 2.9 O-Ring Seal (Option)**

The O-ring, which seals the vacuum chamber must be kept clean and greased for proper operation. Periodically, or whenever the chamber fails to attain proper vacuum, the O-ring, its groove, and the mating surface on the lower chamber should be cleaned. Use a solvent such as methyl alcohol and a soft, clean clothe, then apply a light coating of silicone vacuum grease to the O-ring before replacement.

If either metal sealing surface becomes scratched, it can be polished with the very fine 600grit sandpaper. If the O-ring is damaged, it must be replaced.




***Never put your hand or body inside the chamber without pushing emergency stop button.***

1. Stop the upper chamber at the position where the operator can reach his hand to the O-ring and push the emergency stop button.
2. Straighten the O-ring and find the 'A' position shown in below figure.



3. Insert the 'A' position of O-ring in the '#1' corners of the groove of the clamping frame.
4. Insert the O-ring in the other corners ('#2'). It is important that the O-ring hang slack equally.
5. Insert the O-ring in the half point of the each part as the below drawings..(#3 >#6)
6. Insert the O-ring in the all of the groove and check that there is no protrusion.



## 10.3 Laminator Upper Release sheet

### 10.3.1 Cleaning

The laminating platen may be covered with a Teflon release sheet, adhered to the platen. The area under the O-ring tends to get dirty especially. The surface can be cleaned with methanol and soft cloths. If the surface becomes worn out, it can be replaced.




### 10.3.2 Replacing

It is necessary to replace the sheet when the damage is large or the stacked EVA will not come off.

The upper Teflon sheet is sandwiched by bars at both ends and fixed to the upper chamber frame.




### 10.3.3 Cleaning

The conveyor belt sheet sliding on the platen is to transfer the module and to avoid that the platens get dirty with EVA chips. Clean the sheet surface with the lug and cleaning liquid such as alcohol when the surface is dirty. Replace it when the damage is large.



### 10.3.4 Replacing of Conveyor sheet

It is necessary to replace the conveyor belt sheet when the sheet is damage or the stacked Eva will not come off. Follow the next procedure.




1. Entirely open the upper chamber on the “Manual operation” screen.
2. Rotate the conveyor on the “Manual operation” screen, before the edge clamping bar is



- located in the platen.
3. Take off the rear plate on the rear of the edge clamping bar.
  4. Rotate the conveyor on the “Manual operation” screen, before the center clamping bar is located in platen.
  5. Take off the center clamping bar and the rear plate on the front.
  6. Rotate the conveyor on the Rotate the conveyor on the “Manual operation” screen, Before the edge clamping bar is located in platen.
  7. Take off the front platen from the front of the edge clamping bar
  8. Remove the conveyor belt sheet.
  9. Cut the same size as conveyor belt sheet, Make a hole the same diameter at the same position.
  10. Install the new sheet at clamping bar.

### 10.3.5. Compressor Speed Controlling

If it needs to control the compressor speed, adjust each leakage controller.



1. To slow down the compressor speed, Turn the knob into clockwise direction..
2. To Speed up the compressor speed, Turn the knob into counterclockwise direction.
3. Operate the laminating process without module, Check the new speed with monitoring 'leak speed' on the 'AUTO' screen.


The dust in the air occurs to block the silencer, so that can be the low compressor speed. to prepare for this, The silencer must be cleaned and replaced.

### 10.3.6 AIR Components

#### 10.3.7 Primary air supply

The machine requires the pressure with 0.4Mpa or more. Check the air pressure at the pressure gauge.

The water or impurities in the air supply will be separated and piled in the filter case installed at the air inlet. Drain the piled by turning the drain knob regularly.



#### 10.4 REPLACEMENT OF PRESSURE DIAPHRAGM




It is important that all components of the diaphragm be at the same temperature when replacing.

If the pressure diaphragm is punctured or torn, it must be replaced. To replace the diaphragm perform the following steps :

1. Draw the rectangular lines on the surface .

The lines are decided as follows;

**Outline of the upper chamber - 2%**



Diaphragm

For example ;

Outline of the upper chamber of Laminator 2246 is;


**2,500mm X 4,800mm**

Rectangular line is;:


**2,314 X 4,614mm**

2. Open the upper chamber on the “MANUAL” screen to take off the upper release sheet..

3. Close the upper chamber on the “MANUAL” screen.
4. Leave the heater ON with 130°C or higher
5. Take all clamping leaves off the Hook and hold the ring upward by Carabine hooks



Hook ring



Carabine hooks

6. Open the upper chamber on the “MANUAL” screen and remove the old diaphragm.



**When removed a clamp lever, fix a department with a spring.  
Fixed metal fittings are caught at the time of a rise of upper chamber suddenly, and there is  
Danger that I lift an installation frame..**

7. Lay new diaphragm on the platen and wait until diaphragm has expanded(20~30 min)



**Diaphragm must be expanded by heating to reduce wrinkling.  
The laminator platen is the best heating source for this task.**

8. Turn off the safety curtain on the operating box.
9. Close the upper chamber to the position with some clearance between upper chamber and frame



**This procedure needs the safety curtain off.  
You must pay the attention so that your fingers or the part of the body should not be pinched  
By the chamber.**

10. Pull the diaphragm outward until the marked lines come to edge of the upper chamber.  
Keeping this position of the diaphragm, close the upper chamber fully to clamp it.
11. If necessary, trim the excess diaphragm from the edge of the upper chamber. The cutting  
Dimension is ideally about 130~150mm from the edge of the upper chamber  
so that handling is easy later.
12. Set all clamps on hook and hold their leaves by spring. Open the upper chamber fully  
Manually after setting all the clamp

13. Check the diaphragm visually. If there is large wrinkle, close the upper chamber and unclamp the wrinkled area to eliminate the wrinkle by pulling the diaphragm.
14. Install the release sheet.

## 10.5 TROUBLE SHOOTING

The following table lists the alarm messages that may occur during system operation.

Symptom	Analysis	Corrective Action
Vacuum is not high at all in "Pump"	O-ring out of the groove	Insert the O-ring in the groove firmly
	O-ring has damage	Replace the O-ring
	Upper chamber is not close fully	Reference position is shifted. Home the machine again. If the chamber is not close fully, contact Wooil-Hightech
Vacuum is not high as before in "Pump"	O-ring out of the groove	Insert the O-ring in the groove firmly
	O-ring has damage	Replace the O-ring
	O-ring has dirt	Clean the O-ring.
	Release sheet under the O-ring has dirt.	Replace and Clean the release sheet
	Clamping of Diaphragm is loose.	Adjust the hook shorter to increase clamping power. The four corners can be loose frequently
	Clack on the heater hose in lower chamber.	Open the cover and check the clack on the hose. Contact Wooil-hightech to replace the hose.
	Leak on the vacuum hose or connector.	Replace the hose if it has damage. Tighten up the hose band if it loose. The vacuum inlet area is frequent leaking point.
Vacuum get low when "Press" process begins even "Pump" process is good.	Low vacuum on the pump.	Disassemble and clean the pump. Clean the exhaust line and then operate the pump with gas ballast on.
	Leak on diaphragm	Replace the Diaphragm Contact Wooil-Hightech if replacing does not improve the situation.
Breaker trips due to overload on vacuum pump	The degraded oil in vacuum pump causing the overload.	Replace the vacuum oil. Overhaul the vacuum pump immediately if the noise does not disappear even after the oil change.
The vacuum pump is extremely loud.	The problem is inside of wing.	If the noise is disappeared after replacing the oil, Do prompt action for

		the close inspection.
To get slower the compressor leak speed Low/Mid/Fast.	Silencer or each valve for compressor is blocked.	The compressor speed controlling for each compressor is out of dial, Replace the silencer.
To get longer for draining time.	The silencer is blocked	Replace the silencer.
The difference for heating speed for Platen	The big space between the heater and the platen.	Take off the conveyor belt sheet and retighten up the screws. Do not tighten too hard because the aluminum thread is soft. Contact Wooil-Hightech, If there is no loose on screws.
To get slower heating speed for the Platen.		
Temperature increase more than 10°C immediately after the Upper chamber opens.		
Alarm of broken heater detector.	Wire to heater is off Heater is broken Fuse is broken	Contact Wooil-Hightech
Difference of cooling speed on Platen	Change temperature/pressure of the Note: There is a machine without the cooling function.	Adjust the valve after taking off the front cover.
To get slower heating speed for the Platen		Install some pressure stabilizer for water supply.
The "Ready" status is off.	Damaged wire cover. Start detecting the leak of voltage .	The damaged wire cover happens frequently on the wire to heater in Lower chamber.
Alarm O.T when upper chamber open/close.	The dog or switch position may have shifted on power cylinder.	Horn the machine again. Contact Wooil-Hightech if the problem remains.

We recommend to run the following test program every month without module even there is no problem in production. Then, record the cycle time, vacuum and others. This test will show you the change of the machine status and may find potential problem.